

# Features You Will Love on a versatile PA music centre

# 2710 Series

**Display Screen** shows you all the information for a particular drive, e.g. CD/ USB

**Soft Keys** located below the screen allow you to work your way through the menu their function differs and is detailed on the screen

**USB Socket** connect a USB memory stick to play MP3s

**CD Drive** play your Audio CD's

**\* 1 or 2 Microphone Receiver** allows free convenience when used with wireless microphones

**Remote Control** the unit comes complete with a remote control

## \* Optional Features

**Microphones Sockets** combination jack/XLR balanced/unbalanced ready to plug in a microphone to amplify/record your voice, these accept most commercially available microphones



416

**Desktop Loudspeaker**



427

**Loudspeaker**




**Cue, Speed & Tone selection keys** press the chosen button to select then use the rotary control to cue, slow down or change the treble, bass and balance

**Rotary Control** can control volume, or after pressing the buttons surrounding it, can also adjust speed, cue or tone. Clockwise for more, faster or forward, anti-clockwise for less, slower or back.

**CD/USB/Play /Pause/Previous & Next Selection Keys** all in one area in a familiar intuitive layout.

**Mixer Desk** allows you to set individual volume for both microphones, line input and CD giving you full control of your voice over background music



**Audio line in Socket** Use to amplify iPod, iPad Tablets, Laptops etc

**Line/Aux out Socket** Send audio to another device or amplified speakers 427A

**Digital Input/Output** coaxial and optical connections for loss less audio distribution and connection to apple TV etc

**Speaker Connectors** to connect your Coomber 416, 427, 429 passive loudspeakers for great sound

**2 Headphone sockets** Can also be used for additional line out

**IEC detachable Mains Lead Socket** with fuse.  
Lead supplied with the unit